



Torque & Withdrawal Tester Model 7100

Friborg Test Technology AB

Mail address

P.O. Box 63
SE-196 22 Kungsängen
Sweden

Visiting address

Kraftvägen 32
SE-196 37 Kungsängen
Sweden

T: +46 (0) 8 581 610 10
F: +46 (0) 8 505 961 50

info@friborg.se
www.friborg.se

Technical Specification

- Torque Tester/Screw driver function:
 - Torque tester with analogue scale $\pm 0,50$ Nm
 - Fixing device to clamp the sample/cord
 - Certificate for torque
- Withdrawal Tester:
 - Analogue force gauge push/pull function
 - Range 0-100 N
 - Fixing device to clamp sample/cord



Facts

Standard:

IEC 60335-1 Clause 25

Components:

-

Weight:

Dimensions:

Supply